

使用説明書

Note Plus

Safety Precautions

This manual uses the following symbols to ensure that the XP-PEN Tablet is used correctly and safely. Be sure to read and observe the Safety Precautions.



Do not use this product in a control system area that requires a high degree of safety and reliability.

In such a system, this product could negatively affect other electronic devices and could malfunction due to the effect of those devices.



Turn the power off in areas where use of electronic devices is prohibited.

Turn the power off your tablet when onboard an aircraft or in any other location where use of electronic devices is prohibited, otherwise it may negatively affect other electronic devices in the area. Unplug the USB connector from this product and turn the power off.



Keep the product away from infants and young children.

Accessories to this gadget may present a choking hazard to small children. Keep all accessories away from infants and young children.



CAUTION

Do not place this product on unstable surfaces.

Avoid placing this product on unstable, tilted surfaces or any locations exposed to excessive vibrations. This may cause the tablet to fall or impact surfaces which can result in damage and/or malfunction to the tablet.



Do not place heavy objects on top of this product.

Do not place heavy objects on the product. Do not step on, or place your body weight on this product as this may cause damage.

Avoid extreme high or low-temperature exposure to the XP-Pen tablet.

Do not store this product in areas that drop below 5°C or above 40°C. Avoid locations with excessive temperature fluctuations. This may result in damage to the product and its components.



Do not disassemble

Do not disassemble or modify this product. Doing so may expose you to heat, fire, electric shock and injury. Disassembling the product will void your warranty.



Do not use alcohol for cleaning

Never use alcohol, thinner, benzene or other mineral solvents that may discolor and cause deterioration to the product.



Do not expose to water

Be cautious of water and all liquids that may be near the tablet. Exposure to water or liquid could damage the product.



CAUTION



Avoid placing metallic objects and especially magnetic objects on the tablet.

Placing metallic and/or magnetic objects on this product during operation may cause malfunction or permanent damage.



Do not strike the pen against hard objects.

Striking the pen against hard objects can cause damage to the pen.



Avoid gripping the pen too tightly, and DO NOT use excessive weight/pressure on the Express Key button and pen.

The stylus pen is a high-precision instrument. Avoid pressing too tightly on the Express Key button, and keep any objects from covering the pen to avoid potential damage. Keep the pen away from areas of high dust, contaminants, or any particulate matter that can effect or damage the pen.

Limitation of Liability

1. XP-Pen shall in no event be liable for damages resulting from fires or earthquakes, including those caused by third parties and those arising from user misuse, abuse or neglect.
2. XP- Pen shall in no event be liable for incidental damages- including but not limited to loss of business income, interruption of business activities, corruption or loss of data – that arise from use or failure to use this product correctly.
3. XP- Pen shall in no event be liable for damage resulting from uses not documented in this manual.
4. XP- Pen shall in no event be liable for damages or malfunction arising from the connection to other devices or use of third party software.

目錄

一、軟體概述	1
二、運行環境.....	1
三、使用方法.....	1
1.軟體安裝.....	1
2.軟體運行.....	1
3.用戶狀態.....	2
4.功能說明.....	2
1) 藍牙連接.....	2
2) 首頁.....	3
3) 標籤.....	4
4) 我的.....	4
a) 登錄.....	4
b) 硬體設定.....	4
c) APP設置.....	5
d) 關於Note Plus.....	6

感谢您购买我们的产品。我们的产品用户手册目前支持英语、俄语、日语、德语、韩语、中文、意大利语、西班牙语和法语。如果您的首选语言不受支持，我们深表歉意。

一、軟體概述

XP-Pen Note+是一款記事本APP應用軟體，隨時記錄你工作和生活中的點滴，記錄瞬間靈感和想法。

二、運行環境

本軟體須在Android 6.0、IOS 10.0以上系統運行。

三、使用方法

1.軟體安裝

安卓設備可通過Google Play下載XP-Pen Note+進行安裝；

IOS設備可通過App. Store搜索XP-Pen Note+進行安裝；

2.軟體運行

用戶安裝完成後，點擊桌面上的APP圖示即可進入系統，通過藍牙連接設備後即可開始使用。

首頁如下圖所示：



3.用戶狀態


未登錄：資料僅保留在目前正在使用的移動設備上；

已登錄：資料可在不同設備間共用，需使用Google或Facebook帳號登錄；

4.功能說明

1) 藍牙連接

請前往移動設備中的設置，找到並開啟藍牙服務。

點擊APP首頁右下角按鈕  選擇連接智慧手寫本，選擇Note Plus點擊連接設備，智慧筆記本狀態燈變綠後按功能鍵配對。



登錄狀態下初次連接成功後會綁定智慧記事本，後續使用可實現智慧記事本打開自動連接APP功能。

斷開設備：我的-硬體設定-設備清單，選擇斷開連接。


2) 首頁

新建頁面:按Note Plus功能鍵新增頁面;

搜索:根據輸入資訊查找筆記內容,或選擇按標籤分類篩選;

日期:按照不同日期查找筆記;





離線筆記:智慧手寫板沒有連接APP時也可進行書寫,當連接到APP時可選擇同步資料到APP;



編輯:筆記頁面右下角有藍色編輯標誌,表示APP和Note Plus已經連接,可以即時記錄。在此狀態下Note Plus的輸入內容會顯示在此頁面上,可使用頁面下功能按鈕調整顏色、粗細、畫筆及背景;如需編輯其他頁面,需重新選擇頁面並點擊編輯按鈕進入編輯頁面然後按一下即時,字體變藍色表示切換頁面成功。




顯示:首頁預設按照時間順序排列筆記,選擇筆記可查看詳情。

播放	 播放	頁面筆記內容形成過程
識別	 識別	識別筆記中的文字內容
詳情	 詳情	筆記標籤、時間屬性、備註
刪除	 刪除	刪除筆記
編輯	 編輯	進入編輯狀態
分享	 分享	分享圖片
提示: 識別支持中、英、日、韓、法、德、義大利、西班牙、葡萄牙等九種文字。		


3) 標籤

用戶可自訂創建多個標籤，點擊標籤頁左上角搜索按鈕可查找您所需的標籤和筆記內容。



按一下標籤圖片，可查看此標籤所屬的所有筆記。

標籤封面顯示此標籤所屬筆記數量，左上角可編輯標籤的相關屬性，如名稱、封面等，同時支持對標籤的刪除。




4) 我的

a) 登錄

使用Google或Facebook帳號登錄

b) 硬體設定


已和移動設備配對的Note Plus的硬體屬性，包括設備名稱、記憶體、序號、固件版本等。



c) APP設置


雲端備份：將資料備份到雲端,可實現在不同設備間資料共用，需先登錄帳號；

預設語言：由移動設備系統語言所決定；



d) 關於Note Plus

[查看隱私協議](#)



若有任何的問題，請利用以下方式聯繫我們：

Skype: XP-Pen

Web: www.xp-pen.com

Email: service@xp-pen.com